

Anywhere Interface Box

AIB-3

User Manual

TABLE OF CONTENTS

1. OVERVIEW	3
2. EQUIPMENT LIST	4
3. INSTALLATION.....	4
4. HOME WEB PAGE	5
5. SYSTEM CONFIGURATION WEB PAGE	6
6. GPI EVENTS WEB PAGE.....	8
7. GPO ACTIONS WEB PAGE	9
8. REMOTE DEVICE ASSIGNMENT WEB PAGE.....	11
9. GTP-32 / DC20 RECEIVE EVENTS	13
10. SERIAL PORT CONFIGURATION	14
11. AHSC TRANSMIT ACTION	15
12. AHSC RECEIVE EVENT	16
13. SNMP TX / RX / TRAP ACTIONS.....	17
14. MEM CONFIGURATION.....	18
15. EVENT ACTION TABLE.....	19
16. TALLY ASSIGNMENT WEB PAGE.....	23
17. EXAMPLES: RECEIVE PATTERN MATCHING.....	25
18. EXAMPLES: SEQUENCES.....	28
19. PRODUCT IMAGES.....	29
20. SPECIFICATIONS.....	30
21. DNF CONTROLS LIMITED WARRANTY.....	33

REVISIONS

1.00	08/10/15	Original draft.
1.01	08/24/15	Updated to include new web pages
1.02	10/16/15	Added Tally Assignment web page
1.03	10/07/16	Added SNMP RX/TX and MEM Configuration page
1.04	02/19/18	Added Home Page Buttons & Tally assignment page.

1. OVERVIEW

Go-To Solutions that Save Time, Budget and Get the Job Done

When you need to: Interface It – Monitor It – Control It *The AnyWhere Interface Box!*

The new AnyWhere Interface Box features:

- ✓ Fast Ethernet (100 BASE-T Full Duplex)
- ✓ RS232/RS422 serial port
- ✓ 16- GPI Inputs and 16- GPI Outputs
- ✓ 16- Tally Web Buttons
- ✓ Ability to manage the simplest to the most sophisticated control applications

Use the AIB when you need to:

- Turn on a GPI to send a Serial or Ethernet message / command. Turn off the GPI to send another.
- Fire a GPI to send a TCP, UDP, SNMP, or HTTP message that gets the job done.
- Receive Serial or Ethernet data to turn on/off a GPI Output.
- Receive specific Serial data and then transmit an Ethernet or SNMP notification.
- Receive Ethernet data and generate a replacement Serial command.
- Trigger a simple or complex sequence of actions from a GPI.
- Periodically send a heartbeat message: "I'm alive!"
- Use a Watchdog timer to transmit an SNMP notification after a time period of no heartbeats.
- Monitor SNMP Traps and turn on GPI Outputs (GPO)

Getting Started.....

1. Go to Installation Section to install the AIB.
2. Go to System Configuration Section to set static IP address, Subnet Mask, and Gateway address.
3. Go to Remote Device Assignment Section to enter IP addresses for remote devices that AIB will communicate with.
4. Go to System Configuration section to set default settings.

2. EQUIPMENT LIST

Qty	Component	DNF Part Number
1	AIB PANEL	AIB-3
1	AIB POWER SUPPLY	included
1	POWER CORD	Included

3. INSTALLATION

- A. Connect supplied power supply to POWER 1 connector. For redundant power option, connect power supplies to POWER 1 and POWER 2 connectors..
- B. Connect Ethernet cable to ETHERNET connector.



Rear View

DEFAULT ETHERNET CONFIGURATION

IP Address: **192.168.10.217**
Subnet Mask: **255.255.255.0**
Gateway: **192.168.10.1**

The AIB is configured using a standard web browser (Safari, Firefox, or Chrome). Enter the AIB's IP address in the Address/ URL bar, typically located at the top of the web browser page, to access the Home Page. Use the links on the left side of the Home Page to access the desired configuration web pages.

All configuration settings are saved in non-volatile memory in the AIB. Settings are retained when power is removed.

Settings may be uploaded to a computer as a configuration file (.dnf) for storage. Configuration files may be downloaded from a computer into the AIB to restore a saved configuration. A configuration file contains all of the AIB's configurations except IP address, subnet mask, and gateway address. The AIB does not support partial configuration upload or download. The configuration file is a not a text formatted file. It cannot be viewed or modified with a text editor.

To access the System Configuration web page, use the following log-on when prompted:

Username: dnfuser
Password: controls

4. HOME WEB PAGE

The screenshot displays the AIB-3 Home Web Page. At the top, there is a yellow header with the DNF CONTROLS logo and the text 'AIB-3 AIB-3'. On the left side, there is a vertical navigation menu with buttons for: Home, GPI Events, GPO Actions, Remote Device Assignment, CTP-32/DC20 Receive Events, Serial Port Configuration, AHSC TX Actions, AHSC RX Events, HTTP GET / POST Actions, SNMP TX/RX Actions, MEM Configuration, Event Action Table, Tally Assignment, Log Out, and System Configuration. A blue link 'Refresh Web Keys' is located above the Tally Web Buttons. The Tally Web Buttons are arranged in two rows of eight. The first row contains buttons 1 through 8, and the second row contains buttons 9 through 16. Buttons 1 and 2 are red and green respectively, with text 'GPO 1 ON' and 'GPO 2 OFF'. Button 3 is yellow with text 'OFF'. Buttons 4 through 8 are black with text 'Key 4' through 'Key 8'. Buttons 9 and 10 are red and green respectively, with text 'GPO 9 ON' and 'GPO 10 OFF'. Buttons 11 through 16 are black with text 'Key 11' through 'Key 16'. In the center of the page, there is a block of system information: Label: AIB-3, Serial Number: 22348, Model: AIB-3, P1 Version: V2.18G, P2 Version: V1.31, Web Version: V1.19E, IP Address: 192.168.10.204, Subnet Mask: 255.255.255.0, Gateway: 192.168.10.1, MAC: 00057980574C, TCP/IP Stack Version: v5.42, Power 1: Detected, and Power 2: Not Detected.

The AIB Home page will display the product details and the Tally Web buttons. The product details will include the software version, network settings and power supply status. Above the product details will be the Tally Web Buttons.

A Tally Web Button is a virtual button designed to emulate the operation of mechanical switches. The tally and operating mode of the Web Buttons can be easily configured by the user for their specific application. Each Tally Web Button can be configured to operate standalone or as part of a radio group. A Tally Web Button can be used as a source event in the Event Action table and can be tied to any downstream action. Additionally, the ON text and OFF text can be displayed on the face of the Tally Web Button via the HOME web page. The ON/OFF text is configured via the Tally Assignment Web page (see below).

The AIB-3 supports a total of 16 Tally Web Buttons.

5. SYSTEM CONFIGURATION WEB PAGE

P1 Software Upgrade:	Use this link to install the P1 upgrade file provided by DNF Controls.
P2 Software Upgrade:	Use this link to install the P2 upgrade file provided by DNF Controls.
Web Upgrade:	Use this link to install the Web pages upgrade file provided by DNF Controls.
Save Configuration to PC:	Use this link to save the AIB's current configuration to a configuration file on a computer. The web browser will prompt for file name and directory. The file extension must be 'dnf'.
Restore Configuration from PC:	Use this link to download a configuration file from your computer to the AIB. The web browser will prompt for directory and configuration file name. The file extension must be 'dnf'.
Set Factory Defaults:	Use this link to reset all AIB configuration settings to factory defaults. This will NOT change the IP address, subnet mask or gateway address. The AIB will automatically reboot.

Enter Label:	Enter label to be displayed on top right of all web pages
Enter the new IP settings below:	Enter the new IP address, Gateway, and Subnet Mask. Click on <u>Save Config</u> to save the new entries. The AIB will automatically reboot.

(Remainder of page is blank)

6. GPI EVENTS WEB PAGE



AIB-3

AIB-3

Home

GPI Events

GPO Actions

Save

[Refresh](#)

Remote Device Assignment

GTP-32/DC20 Receive Events

Serial Port Configuration

AHSC TX Actions

AHSC RX Events

SNMP TX/RX Actions

MEM Configuration

Event Action Table


Log Out

System Configuration

GPI CONFIGURATION					
GPI#	GPI Label	User Defined "ON" State	User Defined "ON" Mode	Debounce (*10 ms)	Currently
1	GPI_1	OPTO ON ▾	Latch ▾	1 ▾	OFF
2	GPI_2	OPTO ON ▾	Latch ▾	1 ▾	OFF
3	GPI_3	OPTO ON ▾	Latch ▾	1 ▾	OFF
4	GPI_4	OPTO ON ▾	Latch ▾	1 ▾	OFF
5	GPI_5	OPTO ON ▾	Latch ▾	1 ▾	OFF
6	GPI_6	OPTO ON ▾	Latch ▾	1 ▾	OFF
7	GPI_7	OPTO ON ▾	Latch ▾	1 ▾	OFF
8	GPI_8	OPTO ON ▾	Latch ▾	1 ▾	OFF
9	GPI_9	OPTO ON ▾	Latch ▾	1 ▾	OFF
10	GPI_10	OPTO ON ▾	Latch ▾	1 ▾	OFF
11	GPI_11	OPTO ON ▾	Latch ▾	1 ▾	OFF
12	GPI_12	OPTO ON ▾	Latch ▾	1 ▾	OFF
13	GPI_13	OPTO ON ▾	Latch ▾	1 ▾	OFF
14	GPI_14	OPTO ON ▾	Latch ▾	1 ▾	OFF
15	GPI_15	OPTO ON ▾	Latch ▾	1 ▾	OFF
16	GPI_16	OPTO ON ▾	Latch ▾	1 ▾	OFF

GPI Label	Enter any 15 characters or symbols. For convenience only. Used in Event Action Table
User Defined ON State	OPTO ON: The GPI is ON when the opto-isolator is energized (powered). The GPI is OFF when the opto-isolator is de-energized. OPTO OFF: The GPI is ON when the opto-isolator is de-energized. The GPI is OFF when the opto-isolator is energized (powered).
User Defined ON Mode	LATCHED: The GPI turns ON and stays ON. The GPI turns OFF and stays OFF. MOMENTARY: The GPI turns ON for a short time and then turns OFF and stays OFF. This pattern repeats every time the GPI become active.
Debounce Time	The time period that the GPI must remain ON to be detected as ON. The selected time is multiplied by 10 milliseconds to compute the actual Debounce time.
Currently	Current state of GPI as defined by User Defined ON State.

7. GPO ACTIONS WEB PAGE


AIB-3
AIB-3

[Home](#)
[GPI Events](#)
[GPO Actions](#)
[Remote Device Assignment](#)
[GTP-32/DC20 Receive Events](#)
[Serial Port Configuration](#)
[AHSC TX Actions](#)
[AHSC RX Events](#)
[SNMP TX/RX Actions](#)
[MEM Configuration](#)
[Event Action Table](#)
[Log Out](#)
[System Configuration](#)

[Refresh](#)

GPO CONFIGURATION						
GPO#	GPO Label	User Defined ON State	Operating Mode	Momentary On Time (*10ms)	Group	Currently
1	GPO_1	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
2	GPO_2	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
3	GPO_3	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
4	GPO_4	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
5	GPO_5	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
6	GPO_6	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
7	GPO_7	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
8	GPO_8	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
9	GPO_9	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
10	GPO_10	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
11	GPO_11	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
12	GPO_12	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
13	GPO_13	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
14	GPO_14	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
15	GPO_15	Relay Closed ▾	Latch ▾	▾	None ▾	OFF
16	GPO_16	Relay Closed ▾	Latch ▾	▾	None ▾	OFF

GPO Label:	Enter any 15 characters or symbols. For convenience only. Used in Event Action Table
User Defined ON State:	<p>RELAY OPEN: The relay is OPEN when the GPO is ON. The relay is CLOSED when the GPO is OFF.</p> <p>RELAY CLOSED: The relay is CLOSED when the GPO is ON. The relay is OPEN when the GPO is OFF (Factory Default).</p>
User Defined Operating Mode:	<p>MOMENTARY: The GPO turns ON, waits for the MOMENTARY ON TIME to expire, and then automatically turns OFF.</p> <p>LATCH: The GPO turns ON and stays ON. The GPO turns OFF and stays OFF.</p> <p>TOGGLE: The GPO alternates states with each GPO ON action. The GPO turns ON if it was previously OFF. The GPO turns OFF if it was previously ON.</p>
Momentary ON Time:	For MOMENTARY operating mode only. ON duration for Momentary GPO. Drop down menu settable from 0.01 sec to 2.0 sec.

Group:	Radio Group RG1 - RG4: Only one GPO in a Group can be ON at a time. Before a GPO is turned ON, all of the other GPOs in the group are immediately turned off. (Break before make)
Currently:	Current state of GPO as defined by User Defined ON State.

8. REMOTE DEVICE ASSIGNMENT WEB PAGE

DNF CONTROLS
AIB-3
AIB-3

[Home](#)

Device Type = Other, this device listens on ports **50001- 50008** for TCP Server, UDP, and SNMP communication.

Remote Device 1: 50001
 Remote Device 2: 50002
 Remote Device 3: 50003
 Remote Device 4: 50004
 Remote Device 5: 50005
 Remote Device 6: 50006
 Remote Device 7: 50007
 Remote Device 8: 50008

For UDP and SNMP transmits, the source port number is the same as the listen port number.

Device Type = USP, GTP-32/DC20, or PKM
 This device listens on port 161 and transmits using source port number 161.

Communication Error = 2 missed Heartbeat or Comm Periods

[Refresh](#)

[GPI Events](#)

[GPO Actions](#)

[Remote Device Assignment](#)

[GTP-32/DC20 Receive Events](#)

[Serial Port Configuration](#)

[AHSC TX Actions](#)

[AHSC RX Events](#)

[SNMP TX/RX Actions](#)

[MEM Configuration](#)

[Event Action Table](#)

[Log Out](#)

[System Configuration](#)

REMOTE DEVICE LIST											
Device #	Remote Device Label	Device Type	Primary /Backup Pair	Connection Type	Connection Mode	UDP Attempts	IP Address	Port Number	Heartbeat/ Comm Period (seconds)	Connection Status	
1	Remote Device 1	GTP-32/DC20	None				192.168.10.205		5	Connected	
2	Remote Device 2	USP					0.0.0.0		5	-----	
3	Remote Device 3	USP					0.0.0.0		5	-----	
4	Remote Device 4	USP					0.0.0.0		5	-----	
5	Remote Device 5	USP					0.0.0.0		5	-----	
6	Remote Device 6	USP					0.0.0.0		5	-----	
7	Remote Device 7	USP					0.0.0.0		5	-----	
8	Remote Device 8	USP					0.0.0.0		5	-----	
9	SERIAL								DISABLED	-----	

Remote Device Label:	Enter up to 32 characters. The label will be used in the Event Action Table device drop down menu.
Device Type:	<p style="text-align: center;">USP: Select to connect to other DNF Controls Universal Switch Panels and AnyWhere Interface Boxes.</p> <p style="text-align: center;">GTP-32/DC20: Select to connect to a DNF GTP-32 or DC20/21.</p> <p style="text-align: center;">USP3-API: Select to connect with the USP3-API.</p> <p style="text-align: center;">OTHER: Select to connect to other Ethernet devices.</p>
Connection Type:	For OTHER Device Types only- Select UDP, SNMP, SNMP TRAP, TCP/IP or HTTP GET POST
Connection Mode	<p><u>For TCP/IP Only</u></p> <p style="text-align: center;">Client Transmit: Establish connection to remote device. Transmit command. Disconnect from remote device.</p> <p style="text-align: center;">Client Transmit/Receive: Establish connection to remote device. Maintains connection to remote device.</p> <p style="text-align: center;">Server Receive/Transmit: Accept connection from client. Only client at assigned IP Address can connect. The client is responsible for maintaining connection.</p> <p><u>Server Mode only</u></p> <p>AIB listens on the following ports: Port 50001 for connection from Remote Device 1 Port 50002 for connection from Remote Device 2 Port 50003 for connection from Remote Device 3 Port 50004 for connection from Remote Device 4</p>

UDP Attempts	<u>For UDP Connection Type only</u> The number of times that the message will be sent separated by 10 milliseconds. Since UDP does not provide guaranteed delivery, UDP Attempts provides more than one transmit attempt to deliver the message.
IP Address	Enter IP address for remote device to be controlled or monitored
Port Number	Destination port number for transmit actions Source port number for receive events. Set to '0' to receive events from any port number at remote device IP address.
Heartbeat Rate	<u>For USP and GTP-32/DC20 Device Types</u> Default value is 5 seconds. Communication error is defined as loss of two consecutive heartbeats.
Connection Status	<u>For USP, GTP-32/DC20 device types and TCP/IP connection types only</u> Displays "Connected" in green when communicating with remote device Displays "-----" when NOT communicating with remote device or no IP address has been entered.
Save Button	Click on Save button to save entered settings
Refresh Link	Click on Refresh link to refresh Connection Status

(Remainder of page is blank)

9. GTP-32 / DC20 RECEIVE EVENTS




- Home
- GPI Events
- GPO Actions
- Remote Device Assignment
- GTP-32/DC20 Receive Events
- Serial Port Configuration
- AHSC TX Actions
- AHSC RX Events
- SNMP TX/RX Actions
- MEM Configuration
- Event Action Table
- Log Out
- System Configuration

GTP-32/ DC20 RECEIVE EVENTS			
Line#	Event Label	GTP-32/ DC20 Event Label	User Register Value (for UR_ labels only)
1	FIRE	GPO_25	
2	EVENT LABEL 2		
3	EVENT LABEL 3		
4	EVENT LABEL 4		
5	EVENT LABEL 5		
6	EVENT LABEL 6		
7	EVENT LABEL 7		
8	EVENT LABEL 8		
9	EVENT LABEL 9		
10	EVENT LABEL 10		
11	EVENT LABEL 11		
12	EVENT LABEL 12		
13	EVENT LABEL 13		
14	EVENT LABEL 14		
15	EVENT LABEL 15		
16	EVENT LABEL 16		

Event Label:	Enter any 32 characters. This label is used in the Event Action Table.
GTP-32/ DC20 Event label:	Enter the GTP-32 or DC20 Event Label to tally. This Event Label must be listed in the GTP-32/ DC20's Event Notification Table with the IP address of this USP3. The entered Event Label must exactly match the event label in the Event Notification Table.
User Register Value:	<u>For use with "UR " event labels only</u> Enter a value '0' to '255'. When the received User Register value matches the entered value, the event turns ON momentarily

NOTE- The GTP-32/ DC20 Receive Event type event is only displayed in the Event Action Table for Remote Devices of Device Type "GTP-32/ DC20".

10. SERIAL PORT CONFIGURATION


AIB-3
AIB-3

- Home
- GPI Events
- GPO Actions
- Remote Device Assignment
- GTP-32/DC20 Receive Events
- Serial Port Configuration
- AHSC TX Actions
- AHSC RX Events
- HTTP GET / POST Actions
- SNMP TX/RX Actions
- MEM Configuration
- Event Action Table
- Tally Assignment
- Log Out
- System Configuration

SERIAL PORT CONFIGURATION	
PORT CONFIGURATION:	RS422 CTRL ▾
BAUD:	38400 ▾
PARITY:	ODD ▾
DATA BITS:	8

Port Configuration:	RS232 DTE or RS422 Controller
Baud Rate:	300, 1200, 2400, 4800, 9600, 19200, 38400
Parity:	None, Odd, Even
Data Bits:	Fixed at 8
Stop Bits:	Fixed at 1
Start Bits:	Fixed at 1

11. AHSC TRANSMIT ACTION

DNF
CONTROLS
AIB-3
AIB-3

Home

GPI Events

GPO Actions

Remote Device Assignment

GTP-32/DC20 Receive Events

Serial Port Configuration

USAGE:
Action Label is 1 - 32 characters in length. Use 'A' - 'Z', 'a' - 'z', and '0' - '9'. Label is for convenience only. Used in Event Action Table.

ASCII/HEX Command is 1 - 256 characters in length.
Use %xy to enter HEX value. x and y are values 0 - 9 or A - F. Two characters must follow %.
Use %BR to add serial BREAK (18 bit times). Valid only at beginning of command followed by at least one character.
Use %WTttt to add WAIT. Transmit command up to %WT. Wait ttt time, 001 - 999 milliseconds. Transmit next part of command.
NOTE-%WT is only an approximate wait time.

NOTE- Spaces between characters are NOT transmitted. Use %20 to transmit a space character.

AHSC TRANSMIT ACTIONS		
Line#	Action Label	ASCII/HEX Command
1	AHSC Transmit 1	
2	AHSC Transmit 2	
3	AHSC Transmit 3	
4	AHSC Transmit 4	
5	AHSC Transmit 5	
6	AHSC Transmit 6	
7	AHSC Transmit 7	
8	AHSC Transmit 8	
9	AHSC Transmit 9	
10	AHSC Transmit 10	
11	AHSC Transmit 11	
12	AHSC Transmit 12	

Action Label:	Enter any 32 characters. This label is used in the Event Action Table.
ASCII/ HEX Command:	<p>The ASCII/HEX Command is 1 - 256 characters in length.</p> <p>Use %yz to enter a HEX value. 'y' and 'z' are values 0 - 9 or A - F. Two characters must follow %.</p> <p>Use %WTttt to add a WAIT time, 001 - 999 milliseconds. Three numbers must follow %WT. The characters preceding %WT are sent immediately. The characters after %WTttt are sent after the wait time expires. More than one %WT can be included in a command. NOTE- %WT is only an approximate wait time.</p> <p>For SERIAL only- Use %BR to add a BREAK character as the first transmitted character.</p> <p>NOTE- Spaces between characters are NOT transmitted. Use %20 to transmit a space character.</p>

12. AHSC RECEIVE EVENT



Home

GPI Events

GPO Actions

Remote Device Assignment

GTP-32/DC20 Receive Events

Serial Port Configuration

AHSC TX Actions

AHSC RX Events

SNMP TX/RX Actions

MEM Configuration

Event Action Table

Log Out

System Configuration

USAGE:

Event Label is 1 - 32 characters in length. Use 'A' - 'Z', 'a' - 'z', and '0' - '9'. Label is for convenience only. Used only in Event Action Table.

ASCII/HEX Receive Data is 1 - 16 character patterns in length. Use %yz to enter a HEX value. y and z are values 0 - 9, A - F, or 'X'. Two characters must follow '%'. Use %Xz to match only z. Use %yX to match only y. Use %XX to ignore value.

Use #yyyyyyyy to match an exact bit pattern. Y values are '0', '1', or 'X' (don't care). Use <yyyyyyyy to match any bit in the bit pattern. Y values are '0', '1', or 'X' (don't care).

Use '!' to NOT match a character pattern. Example: Event Label= TEST. Receive Data= !A If any character other than 'A' is received, then TEST event is ON. If 'A' is received, then TEST event is OFF. Use !y, !%yz, or !#yyyyyyyy to specify a NOT pattern match.

NOTE: Spaces between patterns are ignored. Use %20 to match a space character.

AHSC RECEIVE EVENTS		
Line#	Event Label	ASCII/HEX Receive Data
1	AHSC Receive 1	
2	AHSC Receive 2	
3	AHSC Receive 3	
4	AHSC Receive 4	
5	AHSC Receive 5	
6	AHSC Receive 6	
7	AHSC Receive 7	
8	AHSC Receive 8	
9	AHSC Receive 9	

Event Label	Enter any 32 characters. This label is for convenience only and is used in the Event Action Table.
ASCII/ HEX Receive Data	<p>Enter 1- 16 characters and/or bit patterns to match against received serial data.</p> <p>The received characters must exactly match the order and value of the entered patterns. If a received character does not match the entered pattern, all previous matches are discarded and the match process begins again with the first entered pattern. If more than 1 second elapses between received characters, all previous matches are discarded and the match process begins again.</p> <p>Use %yz to enter a HEX character. 'y' and 'z' are values 0 - 9, A - F, or 'X' (don't care).</p> <p>Enter %Xz to match only the z part of the HEX character. Enter %yX to match only the y part of the HEX character. Enter %XX to ignore the received value.</p> <p>Use #yyyyyyyy to match an exact bit pattern. 'y' values are '0', '1', or 'X' (don't care). For example, enter #0XXX1XXX to match bit7= 0 and bit3= 1. Bit0 is on the far right. Bit7 is on the far left.</p> <p>Use <yyyyyyyy to match any bit in the bit pattern. 'y' values are '0', '1', or 'X' (don't care). For example, enter <0XXX1XXX to match bit7=0 or bit3= 1. Bit0 is on the far right. Bit7 is on the far left.</p> <p>Use '!' to NOT match a character pattern. For example: Event Label= TEST. Receive pattern= !A. If any character other than 'A' is received, then TEST event is ON. If 'A' is received, then TEST event is OFF. Use !y, !%yz, or !#yyyyyyyy to specify a NOT pattern match.</p> <p>NOTE- Spaces between patterns are ignored. Use %20 to match a space character.</p>

13. SNMP TX / RX / TRAP ACTIONS

DNF CONTROLS
AIB-3
AIB-3

Home

GPI Events

GPO Actions

Remote Device Assignment

CTP-32/DC20 Receive Events

Serial Port Configuration

AHSC TX Actions

AHSC RX Events

SNMP TX/RX Actions

MEM Configuration

Event Action Table

Log Out

System Configuration

USAGE:
Action Label is 1 - 32 characters in length. Use 'A' - 'Z', 'a' - 'z', and '0' - '9'. Label is for convenience only. Used in Event Action Table.

Community string is 1 - 32 characters in length. Typical value is 'public'.

Use dot notation to enter Object Identifier(OID). Use decimal values only. ie: 1.2.3.4.5.6.7.8
Maximum decimal value is 99999999

OID VALUE Type:
Integer- Valid decimal values: 0 - 999999
Octet Integer- Valid decimal values: 0 - 999999
Octet String- ASCII or HEX characters
Use %xy to enter HEX value. x and y are values 0 - 9 or A- F.
Two characters must follow %.


SNMP Receive Events:
Received OIDs must start with 1.3.6.1.4.1 to be processed. Contact DNF Control for other formats.
iso(1).org(3).dod(6).internet(1).private(4).enterprise(1)

Received OIDs with NULL OID Value will be processed as momentary events. All other OID Value types will be processed as latching events.

SNMP TRANSMIT ACTIONS / RECEIVE EVENTS						
Line#	Event/Action Label 32 characters maximum	Community 16 characters maximum	Command	OID 100 characters maximum Use dot notation with decimal values	VALUE TYPE	OID VALUE 40 characters maximum
1	SNMP TxRx 1		SET		Null	
2	SNMP TxRx 2		SET		Null	
3	SNMP TxRx 3		SET		Null	
4	SNMP TxRx 4		SET		Null	
5	SNMP TxRx 5		SET		Null	
6	SNMP TxRx 6		SET		Null	
7	SNMP TxRx 7		SET		Null	

Event/Action Label:	Enter any 32 characters. This label is for convenience only and is used in the Event Action Table.
Community:	Community string is 1 - 32 characters in length. Typical value is 'public'.
Command:	SET, GET, GET RESPONSE, TRAP (Receive Only)
Object Identifier (OID):	The OID is 8 - 256 decimal values in length entered in dot notation. Only decimal values are accepted. ie: 1.22.333.4.55.666.7.88. Maximum entered decimal value is 99999999.
Value Type	<p><u>OID Value Type</u></p> <p>Integer: Enter decimal value 0 - 999999 for OID value</p> <p>Octet Integer: Enter decimal value 0 - 999999 for OID value</p> <p>Octet String: Enter 16 alphanumeric characters</p> <p>Null: Set to NULL when no OID value is entered.</p> <p>Any: Receive OID with any OID Value Type and value</p>
OID Value	Enter any 32 characters. This label is for convenience only and is used in the Event Action.

14. MEM CONFIGURATION


AIB-3
AIB-3

Home

GPI Events

GPO Actions

Remote Device Assignment

GTP-32/DC20 Receive Events

Serial Port Configuration

AHSC TX Actions

AHSC RX Events

SNMP TX/RX Actions

MEM Configuration

Event Action Table

Log Out

System Configuration

[Refresh](#)

NOTE: Radio Group setting used by MEM ON Action only

MEM CONFIGURATION			
MEM#	MEM Label	Radio Group	Currently
1	MEM_1	None ▾	OFF
2	MEM_2	None ▾	OFF
3	MEM_3	None ▾	OFF
4	MEM_4	None ▾	OFF
5	MEM_5	None ▾	OFF
6	MEM_6	None ▾	OFF
7	MEM_7	None ▾	OFF
8	MEM_8	None ▾	OFF
9	MEM_9	None ▾	OFF
10	MEM_10	None ▾	OFF
11	MEM_11	None ▾	OFF
12	MEM_12	None ▾	OFF
13	MEM_13	None ▾	OFF
14	MEM_14	None ▾	OFF
15	MEM_15	None ▾	OFF
16	MEM_16	None ▾	OFF

MEM Label:	Enter any 32 characters. This label is for convenience only and is used in the Event Action Table.
Radio Group:	Select from "RG1 - RG6" to put the selected mem into a radio group.


MEM's are used to save an Event In's ON or OFF state and trigger an ON or OFF ACTION. MEMs are also used on the Tally Assignment web page to control LCD Key text and color.

In the Event Action Table, an Event In can turn on, turn off or toggle the state of a MEM. Also, a MEM can be used as an Event In to trigger an ON or OFF ACTION.

For example, a MEM can be used to convert a momentary event into a latching tally. VTR Play status turns on MEM 1. VTR Stop status turns off MEM 1. The LCD Key tallying MEM 1 displays PLAY when MEM 1 is on and STOP when MEM 1 is off.

Please refer to section 18 for example of MEMs FLIP FLOP and RADIO GROUP.

15. EVENT ACTION TABLE



Home Save

EVENT IN -> ACTION OUT TABLE									
Line#	EVENT IN			ON ACTION			OFF ACTION		
	Source	Event Type	Event	Local/Remote Device	Type	Action Label	Local/Remote Device	Type	Action Label
1	Local	GPI	GPI_1	Local	GPO ON	GPO_1	Local	GPO OFF	GPO_1
2	Local	GPI	GPI_2	Local	GPO ON	GPO_1	Local	GPO OFF	GPO_1
3	Local	GPI	GPI_3	Local	GPO TOGGLE	GPO_1	Local	Do Nothing	
4	None								
5	Local	GPI	GPI_1	Remote Device 1	GPI ON Tally	1	Remote Device 1	GPI OFF Tally	1
6	Local	GPI	GPI_1	Remote Device 1	GPI ON Tally	1	Remote Device 1	GPI OFF Tally	1
7	None								
8	Remote Device 1	GTP-32/DC20 Receive	FIRE	Local	GPO ON	GPO_4	Local	GPO OFF	GPO_4
9	Remote Device 1	GTP-32/DC20 Receive	FIRE	Local	GPO TOGGLE	GPO_5	Local	Do Nothing	
10	None								
11	None								
12	None								
13	None								
14	None								
15	None								
16	None								
17	None								
18	None								
19	None								
20	None								
21	None								
22	None								

On an Event Action Table line, select an EVENT IN on the left side of the table and then select an ACTION on the right side. Some events only support ON ACTIONS, so the OFF ACTION entries will be grayed out.

One EVENT IN can trigger more than one ACTION. Select the same EVENT IN on multiple lines and then select an ON or OFF ACTION on each line.

Only EVENTS and ACTIONS associated with the Remote Device's Device Type or Connection Type will be displayed in the drop down menus. If the desired event or action is not displayed, then go to the Remote Device Assignment web page and change the Device Type or Connection Type for the Remote Device.

There are 16 Sequence Timers. Use each Sequence Timer event number in multiple lines as the Event Type to create a sequence of actions. The first Sequence entry from the top of the table will be the first sequence action. The next Sequence entry from the top of the table will be the next sequence action. The Event column time is the delay before that line's action will execute. Use Sequence Start action to start a sequence. Use Sequence Stop/ Reset to stop a sequence. The Sequence will always start at its first line.


E V E N T I N	Source	None (Greys out line) Local Event Remote Device Event Serial
	Event Type	<p>Local: GPI GPI changed from OFF to ON. The selected ON ACTION will execute. GPI changed from ON to OFF. The selected OFF ACTION will execute</p> <p>MEM MEM changed from OFF to ON. The selected ON ACTION will execute. MEM changed from ON to OFF. The selected OFF ACTION will execute</p> <p>Sequence Timer The sequence timer's time has expired. Only ON ACTION is executed. The timer automatically restarts for the time period of the next sequence event in the table. After the last sequence event in the table has expired and its ON ACTION executed, the timer automatically restarts for the time period of the first sequence event in the table.</p> <p>Continuous Timer The Continuous timer's time has expired. Only ON ACTION is executed. The timer automatically starts once "Save" is pressed in the Event Action table. After the timer has expired and its ON ACTION executed, the timer automatically restarts for the time period setup in the Event Action table.</p>
		<p>Remote: AHSC Receive Event A successful pattern match has occurred for the selected AHSC Receive Event pattern on the selected Remote Device. Only ON ACTION is executed. If the AHSC Receive Event pattern is assigned to multiple Remote Devices, only the ON ACTION associated with the Remote Device that received the successful match will execute.</p> <p>GTP-32/DC20 Receive (Only available for Device Type "GTP-32/DC20") An Event Label was received that matched the selected GTP-32/DC20 Event Label on the selected Remote Device. Only ON ACTION is executed. If an Event Label is assigned to multiple Remote Devices, only the ON ACTION associated with the sending Remote Device will execute.</p> <p>USP Keypress (Only available for Device Type "USP")</p>
Event	<p>GPI Number, AHSC Receive Event Label, Ethernet Receive Event Label, or GTP-32/DC20 Event Label, Sequence Timer time period. The display labels in the drop down menus are the same user entered labels on the event web pages</p>	

O N A C T I O N	Local / Remote	Execute Action on Local USP3 Execute Action on Remote Device
	Type	<p>Local: GPO Do Nothing Turn GPO ON Turn GPO OFF</p> <p>MEM Do Nothing Turn MEM ON Turn MEM OFF</p> <p>Sequence Start Start identified sequence at its first line in the Event Action Table.</p> <p>Sequence Stop / Reset Immediately stop sequence.</p> <p>Sequence Toggle Toggle current sequence.</p> <p>Sequence Repeat Repeat current sequence</p> <p>Key Enable Turn ON Key Enable Turn OFF Key Enable Toggle Key Enable</p> <p>Redundant Turn ON Redundant Mode Turn OFF Redundant Mode Toggle Redundant Mode</p> <p>Main/Backup Select MAIN Select BACKUP Toggle between MAIN/BACKUP</p> <p>Restart Timer Restarts the currently selected timer in the Event Action Table.</p>
		<p>Remote:</p> <p>AHSC Transmit Action Transmit the selected AHSC Action command. If command contains WAIT (%WT), then transmit all characters prior to %WT, wait for the time period defined by %WT, and then transmit the remaining characters or until the next %WT. A command may contain more than one %WT.</p> <p>GTP-32/ DC20 (Only available for Device Type "GTP-32/DC20") Transmit GPI ON (as a Key Press), GPI OFF (as a Key Release), GPO ON, and GPO OFF messages to a GTP-32 /DC20 Remote Device.</p> <p>USP (Only available for Device Type "USP") Transmit a Key Press to a Remote USP panel.</p>
Action Label	GPO Number AHSC Transmit Action	

O F F A C T I O N	Local / Remote	Execute Action on Local USP3 Execute Action on Remote Device
	Type	<p>Local: GPO Do Nothing Turn GPO ON Turn GPO OFF</p> <p>MEM Do Nothing Turn MEM ON Turn MEM OFF</p> <p>Sequence Start Start identified sequence at its first line in the Event Action Table.</p> <p>Sequence Stop / Reset Immediately stop sequence.</p> <p>Sequence Toggle Toggle current sequence.</p> <p>Sequence Repeat Repeat current sequence</p> <p>Key Enable Turn ON Key Enable Turn OFF Key Enable Toggle Key Enable</p> <p>Redundant Turn ON Redundant Mode Turn OFF Redundant Mode Toggle Redundant Mode</p> <p>Main/Backup Select MAIN Select BACKUP Toggle between MAIN/BACKUP</p> <p>Restart Timer Restarts the currently selected timer in the Event Action Table.</p>
		<p>Remote:</p> <p>AHSC Transmit Action Transmit the selected AHSC Action command. If command contains WAIT (%WT), then transmit all characters prior to %WT, wait for the time period defined by %WT, and then transmit the remaining characters or until the next %WT. A command may contain more than one %WT.</p> <p>GTP-32/ DC20 (Only available for Device Type "GTP-32/DC20") Transmit GPI ON (as a Key Press), GPI OFF (as a Key Release), GPO ON, and GPO OFF messages to a GTP-32 /DC20 Remote Device.</p> <p>USP (Only available for Device Type "USP") Transmit a Key Press to a Remote USP panel.</p>
Action Label	GPO Number AHSC Transmit Action	

16. TALLY ASSIGNMENT WEB PAGE

Use this page to assign the tally source, text legend, font size, and tally color to each Tally Web Button.



Home

GPI Events

GPO Actions Redundant Mismatch Color: Dark

Remote Device Assignment

GTP-32/DC20 Receive Events

Serial Port Configuration

AHSC TX Actions

AHSC RX Events

HTTP GET / POST Actions

SNMP TX/RX Actions

MEM Configuration

Event Action Table

Tally Assignment

Log Out

System Configuration

TALLY ASSIGNMENTS										
Key #	Current State	Tally Source	Tally Type	Number	Tally	Tally Color	Text	Font Size	Event Label	Value
1	OFF: 0	Local	Follow GPO	1	OFF: Blinking Red	GPO 1 OFF	Normal			
					ON: Flashing Red	GPO 1 ON	Normal			
2	OFF: 0	Local	Follow GPO	2	OFF: Green	GPO 2 OFF	Normal			
					ON: Red	GPO 2 ON	Normal			
3	OFF: 0	Remote Device 1	Follow GTP/DC Extended Tally	3	OFF: Amber	OFF	Normal	ET_TEST_1		
					ET1: Red	GPI1 ON	Normal	ET_TEST_2		
					ET2: Green	GPI2 ON	Normal	ET_TEST_3		
					ET3: Blinking Red		Normal			
ET4: Dark		Normal								
4	OFF: 0	None			OFF: Dark	Key 4	Normal			

Key Number:	The Tally Web Button number.
Tally Type:	<p>Local- Follow Key, Follow GPI, Follow GPO, Follow ENABLE Key, Follow Memory Location (MEM), Follow Sequence (SEQ)</p> <p>Remote- Tally Remote Device: USP, GTP-32/DC20, Other</p>
Tally Source:	<p>Local</p> <p><u>Follow Key</u>- Tally is ON when key is pressed Tally is OFF when key is released</p> <p><u>Follow GPI</u>- Tally is ON when GPI is ON Tally is OFF when GPI is OFF</p> <p><u>Follow GPO</u>- Tally is ON when GPO is ON Tally is OFF when GPO is OFF</p> <p><u>Follow ENABLE</u>- Tally is ON when ENABLE is ON Tally is OFF when ENABLE is OFF</p> <p><u>Follow MEM</u>- Tally is ON when MEM is ON Tally is OFF when MEM is OFF</p> <p><u>Follow SEQ</u>- Tally is ON when Sequence is in progress Tally is OFF when Sequence is not running</p>

Tally Source:	Remote	<p><u>Follow remote USP GPI or GPO-</u> Tally is ON when remote GPI/GPO is ON Tally is OFF when remote GPI/GPO is OFF</p> <p><u>Follow GTP-32 or DC-20- Event Label</u> Tally is ON when Event Label state is ON Tally is OFF when Event Label state is OFF</p> <p><u>Extended Follow GTP/DC-</u> For use with "ET_" Event Labels only Formatted: ET_NameField_StatusField The Extended Tally is off when received ET Event Label matches Name Field but does not match any Status entries assigned to key or matches OFF entry ET1Tally is ON when the received Event Label matches the Name Field and Status Field for ET1 and the Event Label is ON ET2 through ET4 Tally is ON when the received Event Label matches the Name Field and Status Field for ET2 through ET4, respectively, and the Event Label is ON</p> <p><u>Follow GTP/DC User Register-</u> For use with "UR_" Event Labels only The UR Event Label is OFF when User Register value does not match any UR entries for key or matches OFF entry value UR1Tally is ON when the received User Register value matches the UR1 value entry UR2 through UR4 Tally is ON when the received User Register value matches the UR1 through UR4 value entry, respectively</p>
Tally Number:		GPI / GPO Number SNMP Table Entry Number AHSC Table Entry Number
Tally:		OFF / ON OFF / ET1, ET2, ET3, ET4 for Extended Tallies OFF / UR1, UR2, UR3, UR4 for User Register Tallies
Tally Color:		Dark, Red, Green, Amber Flashing Red, Flashing Green, Flashing Amber Blinking Red, Blinking Green, Blinking Amber Dim not supported on AIB-3
Text:		Text displayed on key face for each tally entry
Font Size:		Small: 3 rows x 6 characters per row Normal: 2 rows x 4 characters per row Big: 1 row x 3 characters per row
Event Label:		Manually enter, or cut & paste, the Event Label from the GTP-32's or DC20's Event Notification Table. The event label is case sensitive, may not contain spaces, and must exactly match the Event Notification Table entry. (Refer to the GTP-32 or DC20 User Manual.)
Value:		Enter User Register value to match

17. EXAMPLES: RECEIVE PATTERN MATCHING

NOTE- ASCII and HEX data can be mixed in a user entered pattern. For simplicity only, the examples do not mix ASCII or HEX in a user entered pattern.

ASCII Examples

User Entered Pattern	Received ASCII Data	Notes
ABCD	ABCDEFGH	Successful pattern match of first 4 received characters
ABCD	1234ABCDEFGH	Successful pattern match of 5th, 6 th , 7 th , and 8 th received characters
ABCD	1234A5BCDEFG	No pattern match. User entered pattern must be received as entered.
A %XX C D NOTE- spaces are not included in pattern match	ABCD ACCD AJCD A2CD	The value of the second character in the pattern, %XX, is like a wildcard, so it can be any character. A successful pattern match will result if the first, third and fourth characters are correct. All four received character patterns are a successful pattern match.
A %XX C D	1234ABCDEFGH 1234A5CDEFG 4AKCDE	Successful pattern matches.
A %XX C D	ACD	No pattern match. Four characters must be received.

Hex Examples (Base 16 Numbering)

User Entered Pattern	Received Hex Data (spaces for display only)	Notes
%12 %34	12 34 12 34 56 78 56 78 12 34 9A 56 78 12 34	Successful pattern matches for hexadecimal values 12 and 34.
%X2	12 32 52 A2	The first half of the received Hex value is like a wildcard and can be any value. Only the second half must match the user entered value. Successful pattern matches.
%12 %4X	12 43 12 4A 12 49 56 98 12 49	The second half of the received Hex value is like a wildcard and can be any value. Only the first half must match the user entered value. Successful pattern matches.
%12 %4X	12 34 12 84 12 56	No pattern match.

Binary Examples (Base 2 Numbering)

User Entered Pattern	Received Binary Data (spaces for display only)	Notes
#0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	01011000	Bit 7 is immediately after the '#'. Bit 0 is on the far right. A pattern match occurs only when Bit 7= 0 and Bit3= 1. The received data must exactly match these identified bit values for a match. The values of the other 6 bits are ignored. Successful match.
#0XXX1XXX	01111111 00001000 01101001	Successful pattern matches.
#0XXX1XXX	10001000	No pattern match. Bit 7, on the far left is '1'. It must be '0' to match.
#0XXX1XXX	00000000	No pattern match. Bit 3 is '0'. It must be '1' to match.

User Entered Pattern	Received Binary Data (spaces for display only)	Notes
<0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	01011000	Bit 7 is immediately after the '#'. Bit 0 is on the far right. A pattern match occurs when Bit 7= 0 or Bit3= 1. Only one of the bits in the received data must match. The values of the other 6 bits are ignored Successful match.
<0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	11111111	Received Bit 7 =1. Received Bit 3= 1. At least one identified bit, Bit 3, matches. Successful pattern match.
<0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	10000000	Received Bit 7 =1. Received Bit 3= 0. None of the identified bits match the user entered pattern. No pattern match.
<0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	11111111 00000000 01010101 10101010	Successful pattern matches.
<0XXX1XXX Bit7 = 0, Bit3= 1 All other bits are "Don't care"	11110111 10000000 11010101 10100010	No pattern match.

ASCII Examples

User Entered Pattern	Received ASCII Data	Notes
!A	B	A pattern match is successful when the received character is any character except 'A'.
!A	AAAAAA	All of the received characters are 'A'. No pattern match.
!A	AB	The second character is not an 'A'. The received data is a successful pattern match.
!A	BA	The first character is not an 'A' and is a successful pattern match. The received data is a successful pattern match.
!A	BC	No character is an 'A'. Successful pattern match.
!AB	AB	The first character can be any character except 'A'. The second character must be 'B'. No pattern match
!AB	CB DB ZB	The first character can be any character except 'A'. The second character must be 'B'. Successful pattern match
!AB	CD	The first character can be any character except 'A'. The second character must be 'B'. No pattern match

Hex Examples (Base 16 Numbering)

User Entered Pattern	Received Hex Data	Notes
!%12	12	A pattern match is successful when any value is received except 12. No pattern match.
!%12 34	22 34	A pattern match is successful when any value is received except 12, immediately followed by 34 Successful pattern match.
!%12 34	11 34 21 34 9F 34 87 34	Successful pattern matches.
!%12 34	11 12 34	No pattern match
!%12 34	11 22 34 11 45 34 56	Successful pattern matches

18. EXAMPLES: SEQUENCES

When the Sequence Timer's event time expires, the associated ON Action will execute and then the timer for the sequence's next entry in the Event Action Table will start.

Upon receipt of a Sequence Start action, the timer for the Sequence's first entry in the Event Action Table will start.

Upon receipt of a Sequence Stop action, the sequence will immediately stop. The sequence entry in progress will halt without executing. The next Start action will cause the sequence to start at its first entry in the Event Action Table.

When the last Sequence action executes, the sequence will automatically turn off and stop executing. If the last Sequence action is Sequence Start, the sequence will loop until a Sequence Stop is received.

Example #1 Wait for Sequence Start action and then play sequence until end and stop.

Event Type	Event	Description
Key Press	1	Sequence 1 Start action
Sequence 1 Timer	100ms	Delay 100ms and then execute assigned ON Action
Sequence 1 Timer	1 sec	Delay 1 second and then execute assigned ON Action
Sequence 1 Timer	10 sec	Delay 10 seconds and then execute assigned ON Action
Sequence 1 Timer	100ms	Sequence 1 Start action
Key Press	2	Sequence 1 Stop action

19. PRODUCT IMAGES

AIB-3 Front



AIB-3 Rear



20. SPECIFICATIONS



FRONT PANEL INDICATORS	
POWER:	Power status LED, should always stay solid red when powered ON.
P1:	Processor 1 status led, should always blink green when powered ON.
P2:	Processor 2 status led, should always blink green when powered ON.

REAR PANEL CONNECTORS				
POWER 1:	+12V DC, 3.0Amps			
POWER 2:	Optional power supply for redundant power			
RESET Switch:	Press to reset USP3			
ETHERNET:	RJ45 100baseT, Full Duplex			
S1 Switch:	Press and hold 10 seconds to reset IP address to 192.168.10.217 and configuration to factory default			
SERIAL CONNECTOR:	Pin	RS232 DTE	RS422 Controller	RS422 Device
	1	N/C	Frame Ground	Frame Ground
	2	RxD	Receive A (-)	Transmit A (-)
	3	TxD	Transmit B (+)	Receive B (+)
	4	Tied to 6	Receive Common	Receive Common
	5	Ground	N/C	N/C
	6	Tied to 4	Transmit Common	Transmit Common
	7	N/C	Receive B (+)	Transmit B (+)
	8	N/C	Transmit A (-)	Receive A (-)
9	N/C	Frame Ground	Frame Ground	

REAR PANEL CONNECTORS																																																													
<p style="text-align: center;">GPI CONNECTOR 1-8: Opto-isolator Inputs</p> <p>NOTE: GPI (+) is opto-isolator anode GPI (-) is opto-isolator cathode</p> <p>To WET GPIs: Connect GPI + to nearby +V pin. Connect GPI - to Ground to turn on GPI.</p>		<table border="1"> <thead> <tr> <th>Pin #</th> <th>Description</th> <th>Pin #</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>1</td><td>Ground</td><td>14</td><td>GPI 8 +</td></tr> <tr><td>2</td><td>GPI 8 –</td><td>15</td><td>+V</td></tr> <tr><td>3</td><td>+V</td><td>16</td><td>GPI 7 –</td></tr> <tr><td>4</td><td>GPI 7 +</td><td>17</td><td>GPI 6 +</td></tr> <tr><td>5</td><td>GPI 6 –</td><td>18</td><td>+V</td></tr> <tr><td>6</td><td>+V</td><td>19</td><td>GPI 5 –</td></tr> <tr><td>7</td><td>GPI 5 +</td><td>20</td><td>GPI 4 +</td></tr> <tr><td>8</td><td>GPI 4 –</td><td>21</td><td>+V</td></tr> <tr><td>9</td><td>+V</td><td>22</td><td>GPI 3 –</td></tr> <tr><td>10</td><td>GPI 3 +</td><td>23</td><td>GPI 2 +</td></tr> <tr><td>11</td><td>GPI 2 –</td><td>24</td><td>+V</td></tr> <tr><td>12</td><td>+V</td><td>25</td><td>GPI 1 –</td></tr> <tr><td>13</td><td>GPI 1 +</td><td></td><td></td></tr> </tbody> </table>				Pin #	Description	Pin #	Description	1	Ground	14	GPI 8 +	2	GPI 8 –	15	+V	3	+V	16	GPI 7 –	4	GPI 7 +	17	GPI 6 +	5	GPI 6 –	18	+V	6	+V	19	GPI 5 –	7	GPI 5 +	20	GPI 4 +	8	GPI 4 –	21	+V	9	+V	22	GPI 3 –	10	GPI 3 +	23	GPI 2 +	11	GPI 2 –	24	+V	12	+V	25	GPI 1 –	13	GPI 1 +		
Pin #	Description	Pin #	Description																																																										
1	Ground	14	GPI 8 +																																																										
2	GPI 8 –	15	+V																																																										
3	+V	16	GPI 7 –																																																										
4	GPI 7 +	17	GPI 6 +																																																										
5	GPI 6 –	18	+V																																																										
6	+V	19	GPI 5 –																																																										
7	GPI 5 +	20	GPI 4 +																																																										
8	GPI 4 –	21	+V																																																										
9	+V	22	GPI 3 –																																																										
10	GPI 3 +	23	GPI 2 +																																																										
11	GPI 2 –	24	+V																																																										
12	+V	25	GPI 1 –																																																										
13	GPI 1 +																																																												
<p style="text-align: center;">GPI CONNECTOR 9-16: Opto-isolator Inputs</p> <p>NOTE: GPI (+) is opto-isolator anode GPI (-) is opto-isolator cathode</p> <p>To WET GPIs: Connect GPI + to nearby +V pin. Connect GPI - to Ground to turn on GPI.</p>		<table border="1"> <thead> <tr> <th>Pin #</th> <th>Description</th> <th>Pin #</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>1</td><td>Ground</td><td>14</td><td>GPI 16 +</td></tr> <tr><td>2</td><td>GPI 16 –</td><td>15</td><td>+V</td></tr> <tr><td>3</td><td>+V</td><td>16</td><td>GPI 15 –</td></tr> <tr><td>4</td><td>GPI 15 +</td><td>17</td><td>GPI 14 +</td></tr> <tr><td>5</td><td>GPI 14 –</td><td>18</td><td>+V</td></tr> <tr><td>6</td><td>+V</td><td>19</td><td>GPI 13 –</td></tr> <tr><td>7</td><td>GPI 13 +</td><td>20</td><td>GPI 12 +</td></tr> <tr><td>8</td><td>GPI 12 –</td><td>21</td><td>+V</td></tr> <tr><td>9</td><td>+V</td><td>22</td><td>GPI 11 –</td></tr> <tr><td>10</td><td>GPI 11 +</td><td>23</td><td>GPI 10 +</td></tr> <tr><td>11</td><td>GPI 10 –</td><td>24</td><td>+V</td></tr> <tr><td>12</td><td>+V</td><td>25</td><td>GPI 9 –</td></tr> <tr><td>13</td><td>GPI 9 +</td><td></td><td></td></tr> </tbody> </table>				Pin #	Description	Pin #	Description	1	Ground	14	GPI 16 +	2	GPI 16 –	15	+V	3	+V	16	GPI 15 –	4	GPI 15 +	17	GPI 14 +	5	GPI 14 –	18	+V	6	+V	19	GPI 13 –	7	GPI 13 +	20	GPI 12 +	8	GPI 12 –	21	+V	9	+V	22	GPI 11 –	10	GPI 11 +	23	GPI 10 +	11	GPI 10 –	24	+V	12	+V	25	GPI 9 –	13	GPI 9 +		
Pin #	Description	Pin #	Description																																																										
1	Ground	14	GPI 16 +																																																										
2	GPI 16 –	15	+V																																																										
3	+V	16	GPI 15 –																																																										
4	GPI 15 +	17	GPI 14 +																																																										
5	GPI 14 –	18	+V																																																										
6	+V	19	GPI 13 –																																																										
7	GPI 13 +	20	GPI 12 +																																																										
8	GPI 12 –	21	+V																																																										
9	+V	22	GPI 11 –																																																										
10	GPI 11 +	23	GPI 10 +																																																										
11	GPI 10 –	24	+V																																																										
12	+V	25	GPI 9 –																																																										
13	GPI 9 +																																																												

REAR PANEL CONNECTORS					
<p style="text-align: center;">GPO CONNECTOR 1-8: Isolated Relay Contact Closures</p> <p>To WET GPOs:</p> <p>Connect external power supply output to Common Bus, pin #1.</p> <p>Connect GPO commons to nearby Common Bus pins</p> <p>There is no need to connect power supply Ground to GPO connector</p>	Pin #	Description	Pin #	Description	
	1	Common Bus	14	GPO 8 N.O.	
	2	GPO 8 Common	15	Common Bus	
	3	Common Bus	16	GPO 7 N.O.	
	4	GPO 7 Common	17	GPO 6 N.O.	
	5	GPO 6 Common	18	Common Bus	
	6	Common Bus	19	GPO 5 N.O.	
	7	GPO 5 Common	20	GPO 4 N.O.	
	8	GPO 4 Common	21	Common Bus	
	9	Common Bus	22	GPIO 3 N.O.	
	10	GPO 3 Common	23	GPO 2 N.O.	
	11	GPO 2 Common	24	Common Bus	
	12	Common Bus	25	GPO 1 N.O.	
	13	GPO 1 Common			
<p style="text-align: center;">GPO CONNECTOR 9-16: Isolated Relay Contact Closures</p> <p>To WET GPOs:</p> <p>Connect external power supply output to Common Bus, pin #1.</p> <p>Connect GPO commons to nearby Common Bus pins</p> <p>There is no need to connect power supply Ground to GPO connector</p>	Pin #	Description	Pin #	Description	
	1	Common Bus	14	GPO 16 N.O.	
	2	GPO 16 Common	15	Common Bus	
	3	Common Bus	16	GPO 15 N.O.	
	4	GPO 15 Common	17	GPO 14 N.O.	
	5	GPO 14 Common	18	Common Bus	
	6	Common Bus	19	GPO 13 N.O.	
	7	GPO 13 Common	20	GPO 12 N.O.	
	8	GPO 12 Common	21	Common Bus	
	9	Common Bus	22	GPIO 11 N.O.	
	10	GPO 11 Common	23	GPO 10 N.O.	
	11	GPO 10 Common	24	Common Bus	
	12	Common Bus	25	GPO 9 N.O.	
	13	GPO 9 Common			

21. DNF CONTROLS LIMITED WARRANTY

DNF Controls warrants its product to be free from defects in material and workmanship for a period of one (1) year from the date of sale to the original purchaser from DNF Controls.

In order to enforce the rights under this warranty, the customer must first contact DNF's Customer Support Department to afford the opportunity of identifying and fixing the problem without sending the unit in for repair. If DNF's Customer Support Department cannot fix the problem, the customer will be issued a Returned Merchandise Authorization number (RMA). The customer will then ship the defective product prepaid to DNF Controls with the RMA number clearly indicated on the customer's shipping document. The merchandise is to be shipped to:

DNF Controls
19770 Bahama St.
Northridge, CA 91324 USA

Failure to obtain a proper RMA number prior to returning the product may result in the return not being accepted, or in a charge for the required repair.

DNF Controls, at its option, will repair or replace the defective unit. DNF Controls will return the unit prepaid to the customer. The method of shipment is at the discretion of DNF Controls, principally UPS Ground for shipments within the United States of America. Shipments to international customers will be sent via air. Should a customer require the product to be returned in a more expeditious manner, the return shipment will be billed to their freight account.

This warranty will be considered null and void if accident, misuse, abuse, improper line voltage, fire, water, lightning or other acts of God damaged the product. All repair parts are to be supplied by DNF Controls, either directly or through its authorized dealer network. Similarly, any repair work not performed by either DNF Controls or its authorized dealer may void the warranty.

After the warranty period has expired, DNF Controls offers repair services at prices listed in the DNF Controls Price List. DNF Controls reserves the right to refuse repair of any unit outside the warranty period that is deemed non-repairable.

DNF Controls shall not be liable for direct, indirect, incidental, consequential or other types of damage resulting from the use of the product.

###